









ASSEMBLY INSTRUCTION

PVH39 - 6'0" LOW FOOT END SLATTED BED


HARDWARE LIST

NO	HARDWARE NAME	IMAGE	QTY (PCS)
1	NUTS M8*13		8 PCS
2	HALF MOON WASHER M8		8 PCS
3	RING WASHER M8		8 PCS
4	SPANNER 13		1 PC
5	ALLEN KEY M4		1 PC
6	METAL THREAD M8*80		8 PCS
7	BOLT M6*50		2 PCS
8	WOODEN DOWEL		4 PCS
9	SCREW 4*30		26 PCS




PART LIST


A HEADBOARD = 1 PC




B FOOTBOARD = 1 PC




C SIDE RAILS = 2 PCS




D SLATS = 13 PCS




E CENTRE SUPPORT RAIL = 1 PC




F CENTRE LEGS = 2 PCS



STEP 1




STEP 2




ASSEMBLY INSTRUCTION

PVH39 - 6'0" LOW FOOT END SLATTED BED


STEP 3



STEP 4



STEP 5



STEP 6

